

# M

## M100X/M110X/ M126X/M135X

# FRONT LOADER



### Quick Coupler/ISO-Euro Quick Coupler

You can choose from two types of quick attachment couplers. Both let you quickly attach and detach a wide variety of attachments with a simple operation.



### Single-Lever Control

Fatigue-reducing and very efficient, our single-lever joystick control greatly simplifies front loader operation so you can concentrate more on the work ahead. The Series Circuit makes possible simultaneous boom and bucket operation while the Regenerative Bucket Dump Circuit enables quick dumping for efficient operation with quick cycle times. (Joystick pictured features optional 3rd function valve button.)



### Lifting Power and Height

Two separate boom cylinder fulcrum points (Power position and Height position) give you the option to increase the loader's lifting power or height based on your needs. When using the pallet fork or bale spear, you may want to set the fulcrum to give you more height. For bucket work, a lower setting offers more power.



### Quick Attach/Detach Loader

Attaching and detaching the front loader doesn't get easier, thanks to boom stands and two mounting pins. With easy-on and easy-off simplicity, and without tools, this feature is sure to contribute to your overall operating efficiency.

### Hydraulic Self-leveling Valve (Optional)

The hydraulic self-leveling mechanism gives the operator a clear view ahead because it doesn't require an upper loader link. This function can be switched off for times when bucket angles are more advantageous, for instance, during excavation.

# M

## M100X/M110X/ M126X/M135X

Kubota

# FRONT LOADER




### **Kubota Shockless Ride (KSR) (Optional)**

The KSR helps to minimize fatigue by “smoothing out” the ride of the tractor. This feature is particularly useful when your tasks include a lot of tight turns or lifting and dumping of heavy loads. It makes handling round bales far less jarring.



### **Single-lever Hydraulic Quick Coupler (Optional)**

The quick coupler allows the operator to attach all four hoses at once. This makes attaching and detaching quick and easy, even when you're doing it often.



### **Third Function Valve (Optional)**

The quick coupler allows the operator to attach all four hoses at once. This makes attaching and detaching quick and easy, even when you're doing it often.